

Ugee Chemicals Ltd
Fabric & Home Care
MSG

BP Weight Hopper Load Cell Static Calibration Report

Calibration Date : / /

Shift :

Calibration Operator: / /

Calibration Reason	Description	Failure	Planned	Complaint	Note Deviation Percentage Must not exceed +/- 1%
Before Repair Data					Other Reasons
Visual Check	OK			Parts	
	NOT OK				

Pre verification Checklist:

Follow the next procedure during the Admin's Hopper scale check, and the deviation percentage must not exceed +/- 1%:

No	Term	Ok	Not ok	Notes
1	Check that the Admin's Hopper is free moving and the load cell suspenders are in a good condition			
2	Check that the Admin's Hopper infed pipes don't have sticky buildups forming rigid connection to the hopper			
3	Check that all flexible connectors on the hopper are in good shape			
4	Check that there is no foreign object on the Admin's Hopper			
5	With the discharge valve closed, Read-off Weight measurement from IND 780 display (L1). Add dead weights of known mass (X kg), X=100 kg.			

Note : If the deviation percentage exceeds + or - 1% Perform dynamic calibration and adjustment.
X = 100Kg

Comments:

Name/Sign/Date:

Calibration Operator:

Name/Sign/Date:

4TH EYE CHECK:

SOP OWNER	HSE APPROVAL	QA APPROVAL	AUTHORISATION
 Musa Nasiru Date: 06-June-23	 Adeyemi Adebayo Date: 06-June-23	 Olujide Alawode Date: 06-June-23	 Nadieeb Daramola Date: 06-June-23

Calibration Date : / /
Shift :

Calibration Operator:
Description:

Calibration Reason	Description	Failure	Planned	Compliant	Note - Deviation Percentage Must not Exceed +/- 1% Other Reasons
Before Repair / Maint.					
Visual Check					
OK					

Before Repair / Maint.	Visual Check	OK	NOT OK	Parts

Pre verification Checklist :
Follow the next procedure during the Crutcher scale check, and the deviation percentage must not exceed +/- 1% :

No	Term	Yes	No	Notes
1	Check that the Crutcher is freely mobile and the load cell suspenders are in a good condition			
2	Check that the crutcher infed tubes don't have bulk solids buildups forming rigid connection to the vessel			
3	Check that Minor liquid and R/hase infed line for sticky buildup that may be forming rigid connection with vessel			
4	Check that all flexible connectors on the vessel are in good shape			
5	Check that there is no foreign object on the crutcher			
6	Interrupt Crutcher batch while content is greater than 1400 Kg and discharge valve closed. Read-off Weight measurement from the IND780 display (W _d). Add dead weights of known mass (X kg). X=1000			
7	Read-off Weight measurement which essentially sums Crutcher content and dead weights (W _d)			

Static Calibration Steps:

#	Step	Value	Notes
1	Crutcher Vessel initial weight (should be >1500kg)	W ₀	
2	Crutcher vessel final weight after adding X KG	W _f	
3	Expected Vessel Weight	W _e =W ₀ +X	
4	Deviation Percentage	D%=(W _e -W _f)/W _f *100	

Note: If the deviation percentage exceeds + or - 1% Perform dynamic calibration and adjustment.

X = 300Kg

After calibrations empty the crutcher and add dead weight of 1000kg, to ascertain the sensitivity of load cell on minimal weights

Comments:

Name/Sign/Date
Calibration Operator.

4TH EYE CHECK.

SOP OWNER	HSE APPROVAL	QA APPROVAL	AUTHORISATION
M.A.R.: 08-June-23 Musa Nasiru	Adedoyin Adelabiyi Date: 08-June-23	Oluwade Alawode Date: 08-June-23	Nadeeb Daramola Date: 08-June-23

Ugee Chemicals Ltd
Fabric & Home Care
MSG

Ageing Vessel Load Cell Static Calibration Report.

Calibration Date : / /
Shift :
Calibration Operator:
Note - Deviation Percentage Must not exceed +/- 1%
Other Reasons

Calibration Reason	Failure	Planned	Complaint
Description			
Refill Repair Data			
Visual Check			
OK			
NOT OK			

Pre verification Checklist:
Follow the next procedure during the Ageing vessel scale check and the deviation percentage must not exceed +/- 1%:

No	Term	Ok	Not ok	Notes
1	Check that the Ageing vessel is freely suspended and the load cell suspenders are in a good condition			
2	Check that the Ageing vessel infed pipe don't have sticky buildups forming rigid connection to the vessel			
3	Check that all flexible connectors on the vessel are in good shape			
4	Check that there is no foreign object on the crutcher			
5	Interrupt a Spraying process while content is greater than 1500 Kg and discharge valve closed. Read-off Weight measurement from the IND780 display (Wo). Add dead weights of known mass (X kg). X=6000 kg.			
6	Read-off Weight measurement which essentially sums Ageing vessel content and weights (W)			

Static Calibration Steps :

#	Step	Value	Notes
1	Ageing Vessel initial weight (should be >1500kg)	W_a	
2	Ageing vessel final weight after adding X KG	W_f	
3	Expected Vessel Weight	$W_e = W_a + X$	
4	Deviation Percentage	$D\% = (W_f - W_e) / W_e * 100$	

Note - If the deviation percentage exceeds + or - 1% Perform dynamic calibration and adjustment.

X = 600Kg
Conduct an healthcheck by testing with 1000kg to ascertain loadcell's sensitivity to minimum weight

Name/Sign/Date
Comments:

SOP OWNER  Musa Nasiru	HSE APPROVAL  Adedoyin Adebiyi	QA APPROVAL  Olujide Alawode	AUTHORISATION  Nadeeb Daramola
Date: 08-June-2023	Date: 08-June-2023	Date: 08-June-2023	Date: 08-June-2023

4TH EYE CHECK

Ugee Chemicals Ltd
Fabric & Home Care
MSG

Enzyme feeder Load Cell Static Calibration Report.

Calibration Date

Shift ;

<i>Before Repair Data</i>	<i>Parts</i>
Virtual Check	
OK	
NOT OK	

Pre verification Checklist:

Pre verification Checklist:
Follow the next procedure during the Babender feeder scale check and the deviation percentage must not exceed +/- 1% .

No	Term	Pre verification Checklist:		Notes
		Ok	Not ok	
		Follow the next procedure during the Balobuster feeder scale check and the deviation percentage must not exceed +/- 1%.		

- | | | | |
|---|-----------------------------------------------------------------------------------------------------------------------------------|--|--|
| | | | |
| 2 | Check that the Enzyme feeder infed pipe don't have sticky buildups forming rigid connection to the vessel | | |
| 3 | Check that all flexible connectors on the vessel are in good shape | | |
| 4 | Check that there is no foreign object on the Enzyme feeder | | |
| 5 | With the discharge valve closed, Read-off Weight measurement from RC4 display (L1). Add dead weights of known mass (X kg). X=8 kg | | |
| 6 | Read-off Weight measurement which essentially sums Enzyme feeder content and weights (L2) | | |

Note : If the deviation percentage exceeds + or - 1% Perform dynamic calibration and adjustment.

Comments:

Calibration Operator.

SOP OWNER	HSE APPROVAL	QA APPROVAL	AUTHORISATION
<u>Musa Nasiru</u> Date: 08-June-23	<u>Dry</u> Date: 08-June-23	<u>Oluwadé Olajide</u> Date: 08-June-23	<u>Nadeeb Daramola</u> Date: 08-June-23
<u>Adedoyin Adebiyi</u> Date: 08-June-23			

Name _____ Date _____
EYE CHECK

Uisce Chemicals Ltd
Fabric & Home Care
MSG

LIW Line 1 feeders Load Cell Static Calibration Report.

Calibration Date: / /
Shift:
Calibration Operator:
Calibration Reason: Failure Planned Complaint
Description:
Note - Deviation Percentage Must not Exceed + or - 1%
Other Reasons:

Before Repair Data		Parts	
Visual Check		OK	NOT OK

Pre verification Checklist:
Follow the next procedure during the Brabender feeder scale check and the deviation percentage must not exceed +/- 1%:

No	Step	F1	F2	F3	F4	F5	F6	F7	Notes
1	Check that the Admin LIW feeder is free moving and the load cell suspenders are in a good condition								
2	Check that the Admin LIW feeder infed pipe don't have sticky buildups forming rigid connection to the vessel								
3	Check that all flexible connectors on the vessel are in good shape								
4	Check that there is no foreign object on the Admin LIW feeder								
5	With the discharge valve closed, Read-off Weight measurement from OPT2 display (L1). Add dead weights of known mass (X kg).								
6	Read-off Weight measurement which essentially sums Admin LIW feeder content and weights (L2)								

Note: If the deviation percentage exceeds + or - 1% Perform dynamic calibration and adjustment.
See the table below for the value of the dead weight (X) for each feeder

Feeder	Per centonate	HEDMC	TAED	BR 15	AC BASE	SULPHATE	BP REBLEND	BP BELT	BH BASE	AETS	SEA	TRIBBLEND
Dead weight(X)	20 KG	20 KG	2 KG	20 KG	20 KG	2 KG	2 KG	2 KG	20 KG	2 KG	8 KG	

Name/Sign/Date
Calibration Operator.

SOP OWNER	HSE APPROVAL	QA APPROVAL	AUTHORISATION
Musa Nasiru Date: 08-June-2023	Adedoyin Adebiyi Date: 08-June-2023	Oluwaseun Alawode Date: 08-June-2023	Nadeeb Daramola Date: 08-June-2023

Ugee Chemicals Ltd
Fabric & Home Care
MSG

LIW Line 2 feeders Load Cell Static Calibration Report..

Calibration Date : / /
Shift :

Calibration Operator:

Calibration Reason	Failure	Planned	Complaint	
Description				

Note: Deviation Percentage Must not exceed 1 or -1%

Before Repair Data:		After Repair Data:	
Visual Check		Parts	
OK			
NOT OK			

Pre verification Checklist:
Follow the next procedure during the Bühler feeder scale check and the deviation percentage must not exceed +/- 1%.

No	Term	Ok	Not ok.	Notes
1	Check that the Adminx LIW feeder is free moving and the load cell suspenders are in a good condition			
2	Check that the Adminx LIW feeder infed pipe don't have stuck; buildups forming rigid connection to the vessel			
3	Check that all flexible connectors on the vessel are in good shape			
4	Check that there is no foreign object on the Adminx LIW feeder feeder			
5	With the discharge valve closed, Read-off Weight measurement from OPT12 display (L2). Add dead weights of known mass (X kg).			
6	Read-off Weight measurement which essentially sums Adminx LIW feeder content and weights (L2)			

Static Calibration Sigma :

#	Step	F1	F2	F3	F4	F5	Notes
1	Adminx LIW feeder initial weight	I1					
2	Adminx LIW feeder weight after adding X KG	I2					
3	ExpectedWeight	X					
4	Actual Weight	$d = I2 - I1$					
5	Deviation Percentage	$D = \frac{d - X}{X} * 100$					
6							

Note : If the deviation percentage exceeds + or - % Perform dynamic calibration and adjustment.
See the table below for the value of the dead weight (X) for each feeder

Feeder	petcockbume	HIPM/C	TAFD	BR 15	AC BASE	SULPHATE	FPR/BLEEN	MCAS	GD6	BH BASE	AUS	SEA	TRIBBLEND
	10 KG	20 KG	20 KG	20 KG	20 KG	20 KG	20 KG	20 KG	8 KG	2 KG	20 KG	2 KG	8 KG

Name/Sign/Date
Calibration Operator:
Name/Sign/Date
Name/Sign/Date
4TH EYE CHECK

SOP OWNER  Musa Nasiru Date: 08-June-2023	HSE APPROVAL  Adedoyin Adebowale Date: 08-June-2023	QA APPROVAL  Olujide Alawoshe Date: 08-June-2023	AUTHORISATION Nadeeb Daramola Date: 09-June-2023
-------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------

Ugee Chemicals Ltd
Fabric & Home Care
MSG

Flowmeter Calibration Check Report

Calibration Date : / /

Shift

Calibration Operator:

Calibration Reason

Description

Failure

Planned

Compliant

Note - Deviation Percentage Must not Exceed +/- 1%

Other Reasons

Before Repair/Replace

Visual Check

OK

Parts

NOT OK

Pre Verification Checklist:

Follow the next procedure during the Cutcher scale check and the deviation percentage must not exceed +/- 1%:

No	Step	Term	Yes	No	Notes
1	close the manual valve on the line before the auto-valve				
2	place the sample receptacle				
3	open the calibration/train valve				
4	take the initial weight of the receptacle and return to the drain valve				
5	Record the initial totalized value. Then run the pump at 20% if VFD is available. If not, run at full speed				
6	Stop pump when the receptacle is about 80% filled to avoid spillage. Record the final totalized value				
7					

#	Step	Value	Notes
1	Initial totalized value	<i>L1</i>	
2	Final totalized value	<i>L2</i>	
3	Expected value	<i>SP = L2-L1</i>	
4	Actual value	<i>PV</i>	
5	Difference	<i>A=SP-PV</i>	
6	Deviation Percentage	<i>DV2=A*100/SP</i>	
7			

Note : If the deviation percentage exceeds +/- 1%, report OOI and plan a qualified calibration contractor to calibrate flowmeter

Comments:

Name/Sign/Date
Calibration Operator.

Name/Sign/Date
ATH EYE CHECK

SOP OWNER  Musa Nasiru	HSE APPROVAL  Adeboye Adelabio	QA APPROVAL  Olajide Arawoju	AUTHORISATION  Nadeeb Daramola
Date: 08-June-2023	Date: 08-June-2023	Date: 08-June-2023	Date: 08-June-2023

Procter & Gamble Nig
Fabric & Home Care
MSG

DY99 Load Cell Static Calibration Report

Calibration Date : / /

Shift :

Calibration Operator:

Calibration Reason	Failure	Planned	Complaint	Note: Deviation Percentage Must not exceed +/- 1%
Description				Other Reasons
Before Repair / Part				
Visual Check				
OK				
NOT OK				

No.	Term	Yes	No	Notes
1	Check that the DY99 skid is free moving and the load cell suspenders are in a good condition			
2	Check that the DY99 fitted flange's do not have sticky buildup framing rigid connection to the vessel			
3	Check water inlet line for sticky buildup that may be forming rigid connection with vessel			
4	Check that all flexible connectors on the vessel are in good shape			
5	Check that there is no foreign object on DY99 skid			
6	With the discharge valve closed, read off the weight measurement from the IND560 display (W_0). Add dead weight of known mass (X)kg. $X=10$ kg.			
7	Read-off Weight measurement which essentially sum DY99 skid content and dead weights (W_t)			

Pre verification Checklist : Follow the next procedure during the Cutcher scale check, and the deviation percentage must not exceed +/- 1%.

Static Calibration Steps:	Step	Value	Notes
1	W_0		
2	W_f		
3	W_e $(W_f - W_0)$		
4	$D = (W_e - W_0) / W_0 * 100$		

Note : If the deviation percentage exceeds + or - 1% Perform dynamic calibration and adjustment.
 $\bar{X} = 10\text{Kg}$

Comments:

Name/Sign/Date	Calibration Operator:	4TH F/F CHECK		
SOP OWNER <u>Musa Nasiru</u>	HSE APPROVAL <u>Attedoyin Ndebiyi</u>	QA APPROVAL <u>Oluwadare Ajavokite</u>	AUTHORISATION <u>Nadeeb Daramola</u>	Date: <u>08-June-2023</u>
Date: <u>08-June-2023</u>	Date: <u>08-June-2023</u>	Date: <u>08-June-2023</u>	Date: <u>08-June-2023</u>	

Ugee Chemicals Ltd
Fabric & Home Care
MSG

LIW Load Cell dynamic Calibration Report.

Calibration Date :

Shift :

Calibration Operator:

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

Ugee Chemicals Ltd
Fabric & Home Care
MSG

www.megacenter.it

Name/Sign/Date.....

Name/Sign/Date ..

W. H. YELICK

HSE APPROVAL		QA APPROVAL	AUTHORISATION
SOP OWNER <u>Musa Nasiru</u>	Date: 08-June-23	Olujiide Alawode Date: 08 June 23	Nadeeb Daramola Date: 08 - June 2023
Adedoyin Adebiyi Date: 08-June-2023			

L12/L24 BARCODE SCANNER VERIFICATION

	TASK	Expected Result	Observed Result	Status (Y/N)
	Without scanning any material label, try to use the hoists one after the other to lift material	All the hoists are blocked for use		
	Scan the material label on MCAS big bag. Try to use all the hoists to lift material	MCAS hoist is released for use All other hoists are blocked		
	Scan the material label on Percarbonate big bag. Try to use all the hoists to lift material	Percarbonate hoist is released for use All other hoists are blocked		
	Scan the material label on AC Base big bag. Try to use all the hoists to lift material	AC Base hoist is released for use All other hoists are blocked		
L24 HOISTS	Scan the material label on Sulphate big bag. Try to use all the hoists to lift material	Sulphate hoist is released for use All other hoists are blocked		
	Scan the material label on Triblend big bag. Try to use all the hoists to lift material	Triblend hoist is released for use All other hoists are blocked		
	Scan the material label on SEA big bag. Try to use all the hoists to lift material	SEA hoist is released for use All other hoists are blocked		
	Scan the material label on HEPMC big bag. Try to use all the hoists to lift material	HEPMC hoist is released for use All other hoists are blocked		
	Without scanning any material label, try to use either L12 sulphate or L12 Carbonate hoist to lift material	Both hoists are blocked for use		
L12 HOISTS	Scan the material label on Sulphate big bag. Try to use all the hoists to lift material	L12 Sulphate hoist is released for use All other hoists are blocked		
	Scan the material label on Carbonate big bag. Try to use all the hoists to lift material	L12 Carbonate hoist is released for use All other hoists are blocked		
FP Reblend	Scan the material label on FP Reblend Dumpspot at L24	FP Reblend Setpoint on the Admix Production Page changes automatically according to the Reblend Matrix		
	Without scanning any material label, try to load material into either perfume tank by pressing the start push button for the unloading pump on the corresponding perfume tank	Both perfume tanks are blocked for unloading/refilling		
L12 Perfume Skid	Scan the material label on Spotlight perfume. Try to start the unloading pumps for both perfumes	Spotlight unloading pump is released for use Bel Mondo unloading pump is blocked		
	Scan the material label on Bel Mondo perfume. Try to start the unloading pumps for both perfumes	Bel Mondo unloading pump is released for use Spotlight unloading pump is blocked		

Name/Sign/Date
4TH FIVE CHECK






SOP OWNER		HSE APPROVAL	QA APPROVAL	AUTHORISATION
Musa Nasiru Date:	Mr. Oluwadese Adebiyi Date: 08-June-2023			 Nadieeb Daramola Date: 08-June-2023


ATTACHMENT 15

P&G Nigeria	<p style="text-align: center;">Job Aid ENZYME FEEDER CALIBRATION</p> <p>Originator: Musa Nasiru</p>	Issue Date: 16-Sept.-20 Job Aid No: MSG Job aid 017.0 Page: 1 of 4
-------------	-----------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------


Purpose	To ensure accuracy of enzyme dosage
Start	Whenever enzyme feeder calibration is planned
Materials	<ul style="list-style-type: none">This job aidCotton gloves, latex gloves, 3M600 nose mask

Actions	Steps
1. Prepare for calibration	<ol style="list-style-type: none">Collect 8 kg (4 pieces of standard 2kg weight) from storage location at L18 and move to L21(enzyme room).Stop mixing operation.Check that the feeder is stopped, and that hopper refill valve is in closed positionInspect all flexible connectors on the feeder and remove any source of vibration.Check that the infeed and outfeed points do not have sticky build up forming rigid connection to the vesselCheck that there are no foreign objects on the feederCheck that the enzyme feeder is free moving and that load cell suspenders are in good conditionCheck that the feeder/tray is clean and free of material build up.
2. Perform calibration check	<ol style="list-style-type: none">Read the initial weight of the feeder from the RC4 (enzyme feeder HMI). Record this value as L1(Initial Weight) in the calibration check sheet.


SOP OWNER  Musa Nasiru Date:	HSE APPROVAL  Adedoyin Adebiyi Date: 	QA APPROVAL  Olujide Alawode Date: 	AUTHORISATION  Nadeeb Daramola Date: 
---------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------



2. Put 8Kg (4 pieces of 2kg each) standard weight on the marked positions on the four edges of the feeder. Record this value as X (Expected Weight) in the calibration check sheet



3. Record the final weight of the feeder after placing 8kg weight on the feeder. Record this value as L2(Final Weight) in the calibration check sheet



4. Compute the Actual Weight (A) measurement by the load cell as follows

$$\text{Actual Weight} = \text{Final weight} - \text{Initial weight} = L2 - L1.$$

Record this value as A in the calibration check sheet

5. Calculate the feeder deviation (DV) using the formula

$$\begin{aligned} DV &= (\text{Expected Weight} - \text{Actual Weight}) \times 100 / \text{Expected Weight} \\ &= (X - A) \times 100 / X \end{aligned}$$

Where

X = Expected Weight = standard weight used for calibration

A = Actual weight = Final Weight-Initial Weight = L2-L1

DV = Deviation (in %)

6. Record the value of the Deviation in the calibration check sheet

7. Remove the standard weight and return to the storage location at L18

3. Perform Lever Arm Factor adjustment if the Deviation (DV) is more than $\pm 1\%$

Note that Lever Arm Factor adjustment is the exclusive responsibility of MSG Process Engineer


1. Empty the feeder completely.

2. Clean the feeder of all accumulation and restore to base condition

3. Read the weight display on RC4. The value should be 0(zero), Otherwise press

on the RC4 to scroll down and select 'auto tare' and then press to perform auto tare on the feeder

4. Using the button on the RC4 scroll down to select 'lever arm factor'. Read and record the value as Actual Lever Arm Factor (LFact).



5. Compute new Lever Arm Factor (LFnew) as below
Read feeder initial weight and record the value as W_o
Place a test weight. Record the value of test weight as W_t
Read the feeder final weight and record the value as W₁
$$LF_{new} = LFact \times (W_t / (W_1 - W_o))$$

Enter password XXXX on the RC4
Enter the new lever arm factor and press  to save the value
6. Repeat the calibration procedure and confirm the deviation is between 0 and $\pm 1\%$

Result:

Calibration error is less than 1%
Calibration checklist is properly filled

Task Standard:


- 1 No delay in operation due to lack of communication


P&G Nigeria	<p style="text-align: center;">Job Aid</p> <p style="text-align: center;">LIW FEEDER CALIBRATION</p> <p style="text-align: center;">Originator: Musa Nasiru</p>	Issue Date: 16-Sept.-20 Job Aid No: MSG Job aid 018.0 Page: 1 of 4
-------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------

Purpose To ensure accuracy of Admix Material dosage


Start Whenever LIW feeder calibration is planned

- This job aid
 - Cotton gloves, latex gloves, 3M600 nose mask

Actions	Steps
1. Prepare for calibration	<ol style="list-style-type: none"> 1. Collect standard test weight from storage location at L18 and move to the feeder 2. Stop mixing operation. 3. Check that the feeder is stopped, and that hopper refill valve is in closed position 4. Inspect all flexible connectors on the feeder and remove any source of vibration. 5. Check that the infeed and outfeed points do not have sticky build up forming rigid connection to the vessel 6. Check that there are no foreign objects on the feeder 7. Check that the LIW feeder is free moving and that load cell suspenders are in good condition 8. Check that the feeder is clean and free of material build up.
2. Perform calibration check	<ol style="list-style-type: none"> 1. Read the initial weight of the feeder from the OP12 (L18 LIW feeder HMI). Record this value as L1(Initial Weight) in the calibration check sheet.  <ol style="list-style-type: none"> 2. Put standard test weight on the marked positions on the feeder. Record this value as X (Expected Weight) in the calibration check sheet



3. Record the final weight of the feeder after placing standard weight on the feeder.
Record this value as L2(Final Weight) in the calibration check sheet



4. Compute the Actual Weight (A) measurement by the load cell as follows
Actual Weight = Final weight - Initial weight = L2-L1.
Record this value as A in the calibration check sheet
5. Calculate the feeder deviation (DV) using the formula
$$DV = (\text{Expected Weight} - \text{Actual Weight}) \times 100 / \text{Expected Weight}$$
$$= (X-A) \times 100/X$$


Where

X	= Expected Weight = standard weight used for calibration
A	= Actual weight = Final Weight-Initial Weight = L2-L1
DV	= Deviation (in %)
6. Record the value of the Deviation in the calibration check sheet
7. Remove the standard weight and return to the storage location at L18


3. Perform Lever Arm Factor adjustment if the Deviation (DV) is more than $\pm 1\%$

Note that Lever Arm Factor adjustment is the exclusive responsibility of MSG Process Engineer


1. Empty the feeder completely.
2. Clean the feeder of all accumulation and restore to base condition
3. Read the weight display on OP12. The value should be 0(zero), Otherwise press



4. ON the calibration menu page press button to perform auto tare on the feeder.



5. Scroll to group parameter page and select "Group 4"



6. Read and record the value of Lever Arm Factor as Actual Lever Arm Factor (LFact).
7. Compute new Lever Arm Factor (LFnew) as below
Read feeder initial weight and record the value as Wo
Place a test weight. Record the value of test weight as Wt
Read the feeder final weight and record the value as W1
$$LF_{new} = LFact \times (Wt/(W1-Wo))$$

Enter the New Lever Arm Factor
8. Repeat the calibration procedure and confirm the deviation is between 0 and $\pm 1\%$

Result:

Calibration error is less than 1%

Calibration checklist is properly filled

Task Standard:

1. No delay in operation due to lack of communication

Reviewed By <i>Joseph Ndegonekwa</i> Name <i>J. Ndegonekwa</i> Date: 08-10-2020	Reviewed By <i>Samuel Jumani</i> Name <i>S. Jumani</i> Date: 08-10-2020	Approved By <i>Tolue Aremey</i> Name <i>T. Aremey</i> Date: 08-10-2020
------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------